

Table of Contents

Foreword	ix
Acknowledgements	x
About the Hydraulic Institute	xi

Chapter • One

Purpose, Scope, and Deliverables, 1

1.1 Purpose and Scope	1
1.2 Introduction	1
1.3 Intended Audience	1

Chapter • Two

Flexible Couplings, 3

2.1 Purpose of a Flexible Coupling	3
2.2 Factors Affecting Coupling Selection	3
2.2.1 Torque Capacity	3
2.2.2 Speed Capacity	4
2.2.3 Unbalance	4
2.2.4 Maximum Bore Diameter	4
2.2.5 Misalignment	5
2.2.6 Shaft Attachment	5
2.2.7 Torsional Stiffness	5
2.2.8 Vibration Isolation	6
2.2.9 Operating Environment	6
2.2.10 Electrical Insulation or Conductivity	6
2.2.11 Distance Between Shaft Ends (DBSE)	6
2.3 Types of Flexible Couplings	7
2.3.1 Jaw	7
2.3.2 Wrap	7
2.3.3 Sleeve	8
2.3.4 Tire	9
2.3.5 Grid	10
2.3.6 Gear	10
2.3.7 Disc	12
2.4 Hierarchy of Flexible Couplings	13

Chapter • Three
Installation of Flexible Couplings, 15

3.1	Flexible Coupling Installation Procedures	15
3.1.1	Jaw	16
3.1.2	Wrap	18
3.1.3	Sleeve	19
3.1.4	Flange-mounted Tire	22
3.1.5	Radially Mounted Tire	25
3.1.6	Grid	28
3.1.7	Gear	32
3.1.8	Disc	35

Chapter • Four
Flexible Coupling Maintenance Procedures, 39

4.1	Jaw/Wrap	39
4.2	Sleeve	40
4.3	Flange-mounted Tire	40
4.4	Radially Mounted Tire	41
4.5	Grid	41
4.6	Gear	42
4.7	Disc	42

Appendix A
Coupling Comparisons on Technical Requirements, 45

Appendix B
**Coupling Selection Using Horsepower/100
and Torque Methods, 47**

Appendix C
**Types of Shaft Misalignment Associated
with Flexible Couplings, 49**

Appendix D
Rigid Couplings, 51

D.1	Maintenance	52
-----	-------------------	----

Appendix E
Image Credits, 53

Appendix F
Index, 55

List of Figures

2.1	Close-coupled sleeve coupling	8
2.2	Spacer sleeve coupling	8
2.3	Spacer flange tire coupling (right)	9
2.4	Close-coupled radial mount tire coupling	9
2.5	Close-coupled grid coupling	10
2.6	Close-coupled, flex-rigid gear coupling	11
2.7	Spacer gear coupling	11
2.8	Spacer style disc coupling with two standard hubs	12
2.9	Hierarchy of flexible couplings	13
3.1	Exploded view of a close-coupled jaw coupling	16
3.2	Gap dimension required with a jaw style coupling	17
3.3	Exploded view of spacer jaw coupling	17
3.4	Exploded view of close-coupled wrap coupling	18
3.5	Gap dimension required with a wrap style coupling	19
3.6	The wrap style coupling with a "half-spacer" adapter	19
3.7	Exploded view of close-coupled sleeve coupling	20
3.8	The sleeve style coupling flange spacing measurement is typically taken from the flange faces	20
3.9	Exploded view of spacer sleeve coupling	21
3.10	Example of star pattern method for tightening hardware	22
3.11	Exploded view of close-coupled, flange-mounted tire coupling with Taper-Lock [®] bushings	23
3.12	Flange-mounted tire style coupling cross section	23
3.13	Exploded view of spacer flange-mounted tire coupling	24
3.14	Flange-mounted tire style coupling gap cross-sectional view and gap dimensions	25

3.15	Exploded view of close-coupled radially mounted tire style coupling	26
3.16	Radially mounted tire style coupling gap dimension.	26
3.17	Radially mounted tire style spacer coupling gap dimension.	27
3.18	Exploded view of close-coupled grid coupling	28
3.19	The gap used when installing grid style coupling hubs.	29
3.20	A properly lubricated grid coupling	30
3.21	Exploded view of full spacer grid coupling	31
3.22	Exploded view of close-coupled gear coupling.	33
3.23	Gear coupling orientation and gap dimensions	33
3.24	Exploded view of spacer style gear coupling	34
3.25	Exploded view of a close-coupled disc coupling.	36
3.26	Exploded view of spacer disc coupling.	37
3.27	Distance-between-shaft-ends measurement location on disc coupling with piloted hubs	37
C.1	Shaft misalignment	49
D.1	Example of a rigid coupling used in a vertical pump.	51

LIST OF TABLES

A.1	Types of couplings	46
-----	------------------------------	----